

### **Full-Race ProStreet AC compatible turbo kit modifications.**

The following picture illustrates the necessary modifications required to run a FR AC compatible kit on a Honda B-Series motor.

The tab on the block must be cut or sanded down to clear the downpipe. The AC bracket/motor mount must also be cut to clear the downpipe.

If you have any additional questions about the modifications required, feel free to call us toll free at 866.FullRace or via email at [tech@full-race.com](mailto:tech@full-race.com).

